



For activating PRESET function press ZERO button during 5 sec (only in ABS mode) SET indication will be on screen durring PRESET activated. With buttons PRE + and PRE - possible set preset value.